

Billabong Garden Furniture
ABN 17 490 064 244
4/7 June Street
Coffs Harbour NSW 2450
David & Kate James
Phone 0438 664 916
www.BillabongFurniture.com.au

Assembly instruction, standard “billabong” outdoor settings.

All settings have been pre built then dissembled in the factory to ensure everything fits.

Each setting includes.

2 Pre-assembled leg sections
4 x long table boards
2 x long seat boards
8 x 100mm table top bolts
4 x 200mm seat bolts

For 2.900 or longer tables

2 x 650mm x 50mm thin predrilled strips
16 tec screws

Assembly.

Stand (have two people hold them) the two leg sections opposite each other on flat ground 1.2m apart, with the legs to the outsides.

Matching the numbers, place any table top board on the top and put two 100mm bolts in the holes once lined up.

Place the rest of the boards on top of the legs with the numbers matching the numbers on the leg sections.

Hammer the rest of the 100mm table bolts in and the 200mm seat bolts.

Ensure the end of the table is sitting square.

Tighten all the bolts with nuts and washers under.

For 2.900 or longer tables

Using a drill or tek gun, screw the strips under each end of the table 60mm in from the end. These are required to hold the boards level on top due to the extra over hang.

