

## Billabong Garden Furniture

ABN 17 490 064 244

4/7 June Street

Coffs Harbour NSW 2450

David & Kate James

Phone 0438 664 916

[www.BillabongFurniture.com.au](http://www.BillabongFurniture.com.au)

### Assembly instruction, standard “billabong” outdoor settings.

#### **Each setting includes.**

2 Pre-assembled leg sections – 28 Kg each

4 x 2.3m long table boards - 24 Kg each

2 x 2.3m long seat boards - 24 Kg each

2 x 550mm braces - .5 Kg each

8 x 100mm table top bolts

4 x 200mm seat boards

4 x 50mm tek screws.

#### **Assembly.**

Stand (have two people hold them) the two leg sections opposite each other on flat ground 1.4m apart, with the legs to the outsides.

Matching the numbers, place any table top board on the top and put two 100mm bolts in the holes once lined up.

Place the rest of the boards on top of the legs with the numbers matching the numbers on the leg sections.

Hammer the rest of the 100mm table bolts in and the 200mm seat bolts.

Ensure the end of the table is sitting square.

Tighten all the bolts with nuts and washers under.

Climb under the table and screw one end of a brace to the underside of the table top. Ensure the screw does not go between boards by putting them just left and right of centre. Screw the other end of the brace to the seat support.

